

Product Description

Vibra-TITE Excel Primer N 611 is a flammable but ozone friendly version of Primer N which replaces the original trichloroethane based product. Primer N speeds cure of all anaerobic fluids and assists in speeding fixture times and reducing ultimate cure times.

Typical Applications

Vibra-TITE Excel Primer N is used with all Vibra-TITE anaerobic products but is not recommended for our Gasket Makers. Primer N has an on part life of 30 days.

Procedure for Application

Product is normally hand applied from the bottle by brushing, wiping or spraying onto parts.

Properties

Excel 611 Primer N is a blend of flammable solvents. Care must be taken to avoid flames.

Technical Features

Chemical Base	Heptane / Acetone
Color:	Green
Viscosity	3cps
Shelf Life	.12 months @ 68°F unopened
Flammability	

Cured Performance

Performance is dependent on the anaerobic viscosity, gap fill and type of materials being bonded. However, in typical applications fixture times are achieved in approximately 2 minutes.

Presentation

Bottles.....2 oz, 8 oz (with pump sprayer) Cans.....Gallon

General Information

Storage

Store in cool area out of direct sunlight

Note

Vibra-TITE Excel Primer N can be used by applying the primer to one or both bonding surfaces by spray, wipe or brush. Excel Primer N can be used for batch dipping of large quantities of parts while it also degreases and cleans your parts.

Health & Safety in use

Use in well ventilated area and read MSDS.